

## Programmable, Single-Phase Monitor with Surge Protection

For shipping purposes and to make the installation of the **ICM493** easier, the front panel with the circuit board and contactor is packaged separately.

**Note:** *Install front panel after mounting enclosure and connecting conduit.*

To install front panel:

1. Tilt front panel diagonally and insert the panel in the enclosure, as shown in Figure 1.
2. Lay the front panel horizontally in the enclosure and align the holes on the sides of the enclosure, as shown in Figure 2.
3. Using the two larger screws, provided, and a screwdriver, secure the front panel to the enclosure.



Figure 1



Figure 2