



**Installation Instructions for WV2702 Ice  
Maker Water Valve.**

**Replaces – 242252702**

***Disconnect power before repair. This repair should be made by a  
qualified Service Technician.***

The original valve may have screw on connectors for the internal water lines. This replacement valve is equipped with push on connectors to connect the internal water lines. Follow the below to adapt connectors for the new valve.

1. Make note of the position of the water lines on the valve.
2. After removing the old valve, remove the water lines. Be prepared for some leakage.
3. Using a sharp razor carefully cut and remove the nut ends of the water lines. Make sure not to cut the line too short, cut approximately ½" from the end of the line.
  - *Note - The cut water line should be round and clean. Burrs or cuts that oblong or crush the water line could result in leakage and damage to flooring or surrounding areas.*
4. Insert the cut water line into the appropriate connector.
5. Install the new valve.
6. Turn on water and check for leaks.
7. Check all functions of the valve and check for leaks.